


Reset



The diagram shows a hand holding the SmartGoals remote, with a finger pressing the central reset button (a circle with a '0'). To the right, a diagram of a goal is shown with four corner flags, indicating that the goal is reset to zero.

Bluetooth



The diagram shows a hand holding the SmartGoals remote, with a finger pressing the Bluetooth button (a circle with a Bluetooth symbol). To the right, a text box contains the following information:

Beschikbaar eind 2014
Available end 2014

Hard Reset



The diagram shows a hand holding the SmartGoals remote, with a paperclip inserted into the reset hole. To the right, a diagram of the reset hole is shown with a paperclip inserted, and the text "Hard Reset" is displayed above it.



